

A North Atlantic Communications Company

The Solution Behind The Technology

516-756-9000 516-756-9128

SV9100 Quick Reference

Receiving a call:

- 1. Pick up Handset or Press Speaker
- 1a. press the **ANSWER** key if it is blinking.
- 2. Converse

Placing a call:

- 1. Pick up Handset or Press Speaker
- 2. Dial 9 or Press available Line button
- 3. Dial phone number

Call Internally:

- 1. Pick up Handset or Press Speaker
- 2. Dial extension number or Press programmed One-Touch button
- 3. Voice announce after tone burst or wait for the ring call to be answered

Transferring a call:

With caller on the phone

1. Press Transfer

2. Press **One-Touch button** for party or **Dial extension**

-Wait to Announce caller if you want to screen the call.

3. Hang up

Note: To retrieve a denied call Press Flashing Green button

Transferring a call to vm:

With caller on the phone

- 1. Press Transfer
- 2. Press VMSG on the screen
- 3. Press One-Touch button for party or Dial extension
- 4. Hang up

Conference Call:

- 1. With first party on the phone, Press Conf softkey once
- 2. Place next call (internal or external)
- 3. Once second party answers, Press ADD softkey
- 4. Repeat steps 2 and 3 until all parties are dialed
- 5. On the last caller press the **BEGIN** softkey.

Recall Key:

Press this key to finish your current outside call and hear a dial tone.

Feature:

Used to activate terminal features and setup.

Answer:

When the LED light is lit on this key, you have a second call. Press the key to answer.

MIC:

When this key is lit, you **CAN** be heard on speaker phone and on the handset. If this key is not lit, you are muted.

Redial:

- 1. Press Redial
- 2. Press Volume Up or Down keys to scroll through numbers
- 3. Once on desired number, Pick up Handset or Press Speaker to call

Programming Station Speed Dial Numbers:

- 1. Press Speaker key
- 2. Dial 751
- 3. Press the key you wish to program
- 4. Dial **01** for one-touch
- 5. Enter in phone number (9 + 1 + area code + number)
- 6. Press Hold

To Delete

- 1. Press Speaker key
- 2. Dial **751**
- 3. Press the key you wish to delete
- 4. Dial **000**
- 5. Press **Speaker** to hang up

Call forwarding

- 1. Press Speaker
- 2. Dial 741
- 3. Press 1 to set
- 4. Dial EXT number or External # (9 + 1 + area code + number)
- 5. Press **Speaker** key to hang up

To Cancel

- 1. Press Speaker
- 2. Dial **741**
- 3. Dial **0**
- 4. Press Speaker to hang up

Voice Mail:

To check voicemail from the outside:

- 1. Call your main number
- 2. As soon as you hear the greeting press # + EXT Number
- 3. Enter your security code

For all service related issues please call **516-756-9000** option "**0**" Or email our help desk at <u>helpdesk@nactelsystems.com</u>

You can find this document as well as others on the web at http://www.nactelligence.com