

Main Menu

L Listen to Messages 5

Voice Mail lets callers leave recorded messages for you and lets you leave recorded messages for co-workers. Messages get stored in each person's mailbox. To listen to your messages or use other Voice Mail features, you call your mailbox and access the Main Menu. **Automated Attendant** answers your company's calls with a recorded message and gives dialing instructions for callers to follow.

While listening you can:

RE Record RE ply	73	RL Reverse L istening Order	75	VU Turn V olume U p	88
MF Have M sg Forwarded	63	L Listen to Next M sg	5	VD Turn V olume D own	83
MC M ake C all to Sender	62	B Backup a Few S ecs	2	VN Restore V olume to N ormal	86
TI Get T ime, Date, [Sender]	84	BB Backup to B eginning	22	# Exit Listen Mode	#
SA S Ave Message	72	G Go Ahead a Few S ecs	4	See also "Select Listen Mode" on the Main Menu	
E Erase M sg	3	* Pause/Resume Listening	*		

RS Record & Send a Message 77

While recording you can:

B Backup a Few S ecs	2
BB Backup to B eginning	22
* Pause/Resume	*
E Erase Recording	3
TI Hear T ime/Date	84
# End Recording	#

After entering a mailbox number or name you can:

*	Enter another mailbox number. Or, press N to enter another mailbox name.	*
*R	Request a return receipt. As soon as the recipient listens to your msg, <i>Aspire Mail</i> lets you know by placing a "receipt" in your mailbox. The receipt consists of two parts: the voice prompt " <i>The following return receipt arrived on (date/time) from (name or number),</i> " followed by the msg that was listened to. After you press *R, you can go to the top of this menu.	*7
*U	Tag a message as "urgent" so the message gets priority handling in the recipient's mailbox. Upon logging on to their mailbox, the recipient hears " <i>This is an urgent message</i> " followed by the message.	*8
*C	Tag a message as "confidential." Recipients of confidential messages cannot use the MF command or Auto Forward feature to send the message to another mailbox.	*2
#	Send msg and return to Main Menu.	#
*N	Specify next recipient by the opposite method, then go to the top of this menu.	*6
*	Cancel previous mailbox. If no mailbox recipients remain, go to previous menu. Otherwise, go to the top of this menu.	*
**	Erase msg and go to Main Menu.	**

When done recording you can:

*	Enter mailbox numbers to receive msg, up to 10.	*
*N	Specify recipients by name. After you press *N, follow the voice prompts.	*6
**	Erase msg and return to Main Menu.	**

CM Check or Delete Message 26
Lets you know if a msg that you sent has been listened to. If not listened to, you can delete it. *Aspire Mail* also lets you listen to the msg before you delete it.

G Mailbox Greetings 4
You can have 3 different greetings. *Aspire Mail* plays the greeting you select as "active." If Auto Attendant DND is ON, the Auto Attendant does not ring your phone. Callers immediately hear your greeting. If OFF, the Auto Attendant will try your extension. Callers hear your greeting only if you do not answer or are busy.

RN Record Mailbox Name 76
Aspire Mail will play your mailbox name in the voice prompts instead of your mailbox number.

FD Future Delivery Message 33
Aspire Mail sends the message on the date and time you specify.

PG PaGing Message 74
When a caller tries to reach you, *Aspire Mail* uses the message to page you. If the message is ON, *Aspire Mail* pages immediately. If OFF, *Aspire Mail* pages only if you do not answer.

OP Mailbox Options 67

The mailbox options are as follows:

TI Time and Date	84
SA Sys Admin Options (For Sys Admin Mailboxes only)	72
Select Listen Mode	
1N New Messages	16
1S Saved Messages	17
1H Held Messages	14
1A All Messages	12
These options are also available while listening to a msg.	

S Security Code	Changes or erases your mailbox security code.	7	AT Auto Time-Stamp	Plays the msg time, date and sender after the msg.	28
N Message Notification	Calls co-worker or outside number when you get a msg.	6	CW Call Waiting	Lets a caller send beeps to your ext while you are busy on a call.	29
AH Auto Help	Turns some voice prompts on/off.	24	CA Call Announcing	Lets you know who is calling.	22
AF Auto Forward	Copies your msgs to any mailbox you choose.	23	# Exit Menu	#	

X EXit Mailbox 9

Calling Your Mailbox and Accessing the Main Menu

- To call your mailbox from outside the company:**
1. Dial company phone number _____.
 2. Wait for the Automated Attendant to answer.
 3. Dial # and your mailbox number.
 - Optionally dial * and a co-worker's mailbox number to leave them a message.
 - The codes in your system may be different.
- To call your mailbox from your Aspire extension:**
1. Press Voice Mail key.
 - Optionally press an idle CALL key and dial *8.
 - From a single line extension, lift handset and dial *8 instead.
- To access a feature from your mailbox's Main Menu:**
1. Dial the letters shown to the left of the feature name.
 - The corresponding numbers are shown to the right.
 - The letters you dial to access a feature match some of the letters in the feature name.
 - To get a recorded help message at any time, press 0.