

**Adjusting All the Samsung DCS & iDCS Systems For Daylight Savings Time
Changing date & time on the Samsung DCS & iDCS systems**

With Handset Down

Action

1. Press TRSF Button
2. Enter 200
3. Enter 1234 (Or Your Passcode If Different)
4. Press VOL UP Button
5. Press TRSF Button
6. Press TRSF Button
7. Enter 505
8. Enter Day, Date, & Time (See Below)

- W= Day Of Week (1= Monday, 2= Tuesday, etc.)
MM= Month DD= Day YY= Year
HH= Hour MM= Minute (Enter in military format)
9. Press TRSF Button

Display Will Show

Programming Mode
Enter PGM ID:
Enable Cus. Prog.
Passcode:
Enable Cus. Prog.
Disable
Enable Cus. Prog.
Enable
Normal Idle Display
Programming Mode
Enter PGM ID:
Old: 2 1 0 2 8 9 7: 1 2 0 2
New:WMMDDYY:HHMM
Old: 2 1 0 2 8 9 7: 1 1 0 2
New:WMMDDYY:HHMM

Normal Idle Display
